PE

BuilderCE

PROFESSIONAL ENGINEERING CONTINUING EDUCATION

Construction Safety & OSHA

Hazard Recognition and Field Responsibilities

Self-Paced Course Study Guide

PREVENT

Address design, access and sequence before exposure.

→

ASSIGN

Identify task-specific competence, authority and ownership.

→

VERIFY

Reassess change and confirm the release condition.

Engineering safety begins with prevention, task-specific authority and verified controls.

COURSE	CREDIT / CATEGORY	INSTRUCTOR
ENG-015	1 CEH / PDH · Pertinent to Engineering Construction & Field Practice	John W. Adcox, Jr., Ed.D., CPC

Superior Learning, LLC d/b/a BuilderCE

Course overview. Construction safety begins with a simple discipline: recognize the exposure, understand your role and authority, select or obtain an effective control, and verify the condition before work continues.

Course Purpose

Provide engineers and construction professionals with a practical, role-aware framework for recognizing construction hazards, understanding when OSHA-defined safety roles or specialized technical authority apply, integrating Prevention through Design and the hierarchy of controls into project decisions, and responding to unsafe or changed field conditions without exceeding the individual's competence or contractual authority.

Learning Objectives

- Explain how design, planning, sequencing, temporary conditions, work interfaces and field changes influence construction risk.
- Use OSHA's Construction Focus Four as a rapid hazard-recognition lens while recognizing that detailed requirements and thresholds depend on the specific operation and applicable subpart.
- Apply Prevention through Design and the hierarchy of controls to prefer elimination, substitution and engineering controls when feasible before relying primarily on administrative controls or PPE.
- Distinguish competent-person, qualified-person, registered-professional-engineer and project-role concepts without assuming that job title alone creates authority or responsibility.
- Recognize common risk patterns in excavations, scaffolds/elevated work, cranes/rigging/mobile equipment, temporary electrical systems and multi-employer worksites.
- Apply a field-response sequence that pauses exposure, controls within authority, notifies and escalates appropriately, documents facts and ownership, and verifies correction.
- Identify the current federal severe-event reporting windows as an awareness requirement and distinguish reporting from routine injury/illness recordkeeping.

Course boundary. This course is professional continuing education. It is not OSHA 10-hour or 30-hour Outreach Training, does not issue an OSHA card, and does not replace employer-provided training, a site-specific safety program, a competent-person or qualified-person designation, task-specific procedures, or the current OSHA standard applicable to the work. Project contracts, employer programs, manufacturer instructions, applicable codes and current regulations remain controlling.

Study plan and navigation

MODULE	MINUTES	FOCUS
1	15	Engineering responsibility, PtD and role boundaries
2	15	Focus Four hazard recognition
3	15	High-risk work and specialized roles
4	15	Field response, documentation and verification

Planned instructional time: 60 minutes, exclusive of the final examination. Individual study time may vary.

How to complete this course

Read all modules in this course. No separate module acknowledgement is required. When you have finished reading, select Continue at the bottom of the BuilderCE lesson page to begin the 10-question final examination. If you are reading the PDF, return to that webpage first. A score of at least 70% is required to pass. Retakes are permitted.

MODULE 1 | 15 MINUTES

Engineering safety responsibility, PtD and role boundaries

Construction safety is not only an end-of-process inspection function. Engineers influence exposure through design details, temporary-condition assumptions, access, sequencing, equipment interfaces, material choices and the information they communicate to the field.

1.1 Safety Is a System of Design, Planning, Control and Verification


A construction hazard rarely appears in isolation. The same condition can be created or amplified by design geometry, access constraints, work sequencing, temporary support, delivery routes, adjacent operations, schedule acceleration, weather, substitutions or incomplete information. For that reason, a useful engineering safety model begins before the crew reaches the work area. It asks what decisions can remove the hazard, what controls must exist if the hazard remains, who has authority to implement those controls, and when the control will be verified.

OSHA's safety-management guidance emphasizes proactive hazard identification, prevention and control, worker participation, training, program evaluation and coordination. For engineers, the practical implication is that safety should be treated as a lifecycle design-and-field process rather than a checklist that belongs only to a safety department. A project engineer may not be the employer's safety manager, but engineering decisions can still materially affect whether a dangerous exposure is created, reduced or made easier to control.

1.2 Prevention through Design: Move the Decision Upstream

NIOSH defines Prevention through Design (PtD) as designing work to eliminate hazards or minimize risks before exposure occurs. This is especially relevant to engineers because the ability to influence risk is often greatest while geometry, materials, access, connection details, equipment locations and construction sequences are still being developed. Once work is underway, options may narrow to temporary protection, administrative controls and PPE. PtD does not mean that the design professional assumes the contractor's means-and-methods responsibility. It means the engineer should recognize foreseeable safety implications of engineering decisions and, within the engineer's scope and authority, avoid creating unnecessary hazards or make hazards easier to control.

Examples include providing permanent access where frequent maintenance is expected, designing parapets or guard-compatible details where feasible, avoiding unnecessary work in energized or congested zones, providing adequate clearance around equipment, locating tie-off or anchorage features where they are part of the engineered design, designing components for safer prefabrication or installation, and coordinating lifting or temporary-condition information that is essential to safe execution. The exact solution depends on the project and responsibility allocation; the core principle is to address the hazard at the highest feasible level rather than accepting it and relying entirely on worker behavior.



Prefer feasible elimination, substitution and engineering controls before relying primarily on administrative controls or PPE. Required PPE remains necessary; the hierarchy does not waive a standard.

Practice Point - Control Selection

When reviewing a hazard, do not begin with “What PPE should be worn?” Begin with “Can the hazard be removed, reduced, separated, guarded, isolated or designed out?” PPE remains essential where required, but it is the last layer in the hierarchy, not the default substitute for a feasible higher-order control.


1.3 Role Boundaries Matter as Much as Hazard Recognition

Professional engineers routinely observe work, review submittals, respond to requests for information, evaluate changes, inspect for contract conformance and advise owners or contractors. Those functions may place the engineer close to safety-critical conditions, but proximity does not automatically make the engineer the controlling employer, competent person, qualified person or site safety officer. OSHA responsibilities attach to employers and to roles defined by specific standards, while the engineer's contractual duties and professional obligations arise from the project agreement, licensure law, accepted scope and actual conduct.

A sound response therefore separates three questions. First, what hazard or exposure is present? Second, what authority and competence does this person have? Third, who must make or implement the decision required to control the hazard? An engineer should not ignore an apparent serious hazard merely because another party controls the work; neither should the engineer make specialized safety or means-and-methods decisions outside the engineer's competence or assigned authority. The appropriate action may be to pause an activity within available authority, notify the responsible employer, engage the competent or qualified person, elevate a technical issue, or require clarification before an engineering approval is given.

1.4 Changed Conditions Are New Safety Decisions

Construction is dynamic. An access route that was safe yesterday can become unsafe after excavation. A guardrail can disappear during material movement. Temporary power can expand beyond its original configuration. A crane can be relocated. A design revision can shift loads or require a different installation sequence. Two trades that were planned for separate zones can be compressed into the same work area by schedule changes. The correct response is not to assume that the original plan still controls. A meaningful change is a trigger to reassess the exposure and verify the controls that depend on the changed condition.



Reassess whenever a change can invalidate an exposure assumption or an existing control.

1.5 OSHA Framework and Severe-Event Reporting Awareness

Construction-specific federal OSHA requirements are primarily found in 29 CFR Part 1926. Recordkeeping and severe-event reporting are addressed in 29 CFR Part 1904. A one-hour professional-development course cannot substitute for those standards. The engineer or manager should identify which subparts apply to the actual work and consult the current regulatory text when making compliance decisions.

One important awareness item is the federal severe-event reporting rule in 29 CFR 1904.39. A work-related fatality must generally be reported to OSHA within eight hours. A work-related in-patient hospitalization of one or more employees, an amputation, or a loss of an eye must generally be reported within 24 hours. The rule contains additional provisions addressing delayed outcomes and when the employer learns that an event is reportable. Emergency response and protection of people come first; the organization should also have a preassigned process for deciding who gathers facts, who makes required reports, how timing is documented, and how the event is investigated.

> **Reporting awareness.** Older training materials sometimes state that only hospitalizations of three or more employees required immediate reporting. That is obsolete. The current federal rule uses the 8-hour fatality and 24-hour hospitalization/amputation/loss-of-eye framework described above.

MODULE 2 | 15 MINUTES

Construction Focus Four hazard recognition

The Focus Four categories are useful because they convert a complex construction site into four rapid exposure questions. They are a recognition framework, not a substitute for the detailed standards that govern particular operations.

2.1 Use the Focus Four as a Field Scan, Not a Memorization Exercise

OSHA's Construction Focus Four identifies falls, struck-by hazards, caught-in or -between hazards and electrocution hazards. For engineers and field managers, the value of the framework is not the labels themselves. It is the habit of asking where energy, movement, gravity or changing geometry could put a person in the path of harm. A short field review can begin with four questions: Can someone lose support and fall? Can a moving or falling object strike someone? Can a person be crushed, pinned, engulfed or pulled into a closing space? Can a person or equipment contact hazardous electrical energy?

FALLS	STRUCK-BY
Loss of support at an edge, hole or access route.	A moving object or load reaches a person.
CAUGHT-IN / BETWEEN	**ELECTROCUTION**
A space closes, collapses or draws a person in.	People or equipment contact hazardous electrical energy.

OSHA Focus Four hazard categories support an exposure scan; each operation still requires its applicable standards and controls.

2.2 Falls: Consider the Work Surface and the Route to It

Fall hazards arise at edges, floor and wall openings, roofs, scaffolds, ladders, aerial work platforms, structural frames, formwork and temporary access points. Engineering review should consider both the final work location and the path workers must use to reach it. A protected platform does not solve the exposure if the approach requires crossing an unprotected opening. Similarly, a permanent design may be safe in service but difficult to construct safely if temporary access, connection sequence or fall-protection anchorage has not been considered.

Avoid treating a single height threshold as a universal rule. Many Subpart M construction situations use six feet, but other OSHA subparts and operations use different requirements. Scaffolds, steel erection and certain specialized operations are governed by their own provisions. The professional practice lesson is to identify the actual activity and applicable standard rather than applying a remembered number to every condition.

Engineer's Questions for Fall Exposure

- Where are the edges, holes, leading edges or elevation transitions during each construction phase?
- What temporary or permanent feature provides safe access?
- Will installation or removal of the permanent work temporarily remove a protective feature?
- Does a design detail create a foreseeable need for work in a difficult-to-protect location?
- Who installs, inspects, maintains and restores temporary protection when another trade modifies it?

2.3 Struck-By: Manage Movement, Load Paths and Separation

Struck-by exposures include vehicles, mobile equipment, swinging or suspended loads, falling materials, flying particles and objects released under force. The field-control strategy frequently depends on separation: separating pedestrians from equipment routes, separating workers from suspended-load paths, separating adjacent trades from drop zones, and separating staging areas from active movement. Engineers may influence these conditions through site layout, access planning, temporary traffic configurations, lifting interfaces, structural erection sequencing and review of temporary-condition constraints.

A useful planning concept is the “line of fire.” Identify where an object will travel if a load swings, a component is released, a vehicle turns, a material stack shifts, a pressurized connection separates or a tool ejects material. Then keep people out of that path or create a physical control that prevents the energy from reaching them. Spotters and procedures are valuable administrative controls, but they should not substitute for feasible separation, barricades or engineered restraints.

2.4 Caught-In/Between: Identify Spaces That Can Close

Caught-in or -between hazards occur when a worker can be crushed, pinned, engulfed, pulled into equipment or trapped between moving and fixed objects. Excavation collapse is a prominent example, but the same principle applies to backing equipment, rotating machinery, installation pinch points, shifting materials, temporary structures and heavy components being positioned. An engineer reviewing a sequence or detail should ask how the geometry changes during installation, where a person would need to stand to complete the work, and whether equipment or components can move into that occupied space.

Excavations deserve special attention because soil, groundwater, surcharge loads, spoil placement, utilities, adjacent structures, traffic and weather can change stability. The applicable OSHA excavation standard assigns important functions to a competent person and imposes protective-system requirements. Deep or unusual excavations may require registered-professional-engineer design depending on the selected compliance option and depth. The professional lesson is not to improvise a protective system because the excavation “looks stable.” Follow the standard, competent-person evaluation and engineered design requirements that apply.

2.5 Electrocution: Treat Energy Location as a Design Input

Construction electrical exposure can arise from overhead lines, underground utilities, temporary distribution systems, damaged cords and equipment, wet conditions, unexpected energization and work on or near electrical systems. Hazard recognition begins before work reaches the energized zone. Design records, utility information, field locating, lockout or de-energization planning, clearance requirements and qualified electrical expertise may all be relevant depending on the task.

Temporary power should be treated as a changing system. As a project expands, circuits are extended, panels are added, weather affects equipment, cords move through new routes and additional trades connect loads. A safe configuration at initial installation can become unsafe after weeks of field modification. Responsibility for inspection, protection, routing and changes should therefore remain visible throughout the project.

2.6 Every Control Needs an Owner and a Verification Point

A control that exists only in the plan is not a field control. Guardrails are removed, barricades are moved, exclusion zones are crossed, spotters leave, temporary supports are modified and access routes change. The planning record should identify who owns the control and when it will be verified. Verification may occur before the crew enters, at the start of each shift, after weather, after another trade changes the area, after a design change, before energization or immediately before a lift or equipment movement.

> For shared controls, assign ownership explicitly. A temporary stair, guardrail, crane exclusion zone, energized-area barricade or excavation access route can affect several employers. “Everyone thought someone else had it” is a predictable failure mode.**Practice point.** For shared controls, assign ownership explicitly. A temporary stair, guardrail, crane exclusion zone, energized-area barricade or excavation access route can affect several employers. “Everyone thought someone else had it” is a predictable failure mode.

2.7 Rapid Work-Package Hazard Scan

Before releasing a work package, a short structured scan can expose coordination problems that a generic checklist misses. Describe the work step in plain language, identify the energy or movement involved, identify who can enter the exposure zone, select the highest feasible control, assign an owner, and define the condition that will trigger reinspection or re-planning.

Scan Question	Example Prompt	Release Evidence
Exposure	Where can gravity, motion, pressure, stored energy or electricity reach a person?	Hazard identified and affected zone defined
Control	Can the hazard be eliminated, separated, guarded or engineered before relying on procedure/PPE?	Control selected and available
Ownership	Who installs or maintains the control and who can stop the work?	Responsible role identified
Change trigger	What weather, sequence, access, design, equipment or adjacent-trade change invalidates the plan?	Reassessment trigger stated

Field evidence: recognizing fall exposure



OSHA source photograph

Historic image retained at modest size. Height and hidden protection cannot be determined.

1 OPEN BAYS

A step or loss of balance can remove support.

2 ACCESS / WORK ROUTE

Identify how workers reach and perform the task.

Callouts identify exposure, not a complete violation determination.

OSHA Construction eTool, Falls: original worker-on-beams photograph with separate exposure callouts. The callouts identify support-loss exposure and the need to evaluate access. Measurements and protection details require field verification.

The OSHA image shows a worker among beams and floor openings. Begin with the exposure: a loss of balance or backward step can lead into an opening. The photograph does not establish the height, hidden protection or every fact needed to determine a specific violation. The low-resolution image is evidence of a recognition problem, not a complete compliance evaluation.

CONCEPTUAL PLAN VIEW — NOT AN AS-BUILT OR PROTECTION DESIGN



This diagram does not establish adequate strength, covers, edge protection or fall-arrest suitability.

Original conceptual teaching diagram. Evaluate the route and working position together; an illustrated route is not a protection design or confirmation that a particular cover or guardrail is adequate.

A useful response considers access and the work method, including guarded routes, suitable covers or other properly selected protective systems. “Be careful” leaves the hazard in place. Communicate the location and immediate concern while respecting the employer’s and project’s defined competent-person and qualified-person responsibilities.

Consider whether work can use a protected route or an appropriately designed and secured cover. Personal fall-arrest selection requires system compatibility, suitable anchorage, clearance, rescue planning and the applicable requirements. Do not assume that a visible beam is a suitable anchorage or infer a complete compliance finding from the photograph.

OBSERVE	OBTAIN / VERIFY BEFORE RELEASE
Open bays next to the worker and the route	Location, phase, dimensions, exposure and applicable operation-specific standard.
Access and work method are not established by the image	A feasible controlled route and work position; owner, installation and inspection of the selected protection.
No complete fall-arrest system can be evaluated from this photograph	If used, the required qualified selection, anchorage, compatibility, clearance and rescue arrangements.

Primary source:OSHA Construction eTool — Falls

MODULE 3 | 15 MINUTES

High-risk operations, specialized roles and interfaces

Construction standards use terms such as competent person, qualified person and registered professional engineer for different purposes. A safe project maps the required role to the actual task and gives that person the knowledge and authority the standard requires.

3.1 Competent Person, Qualified Person and Registered Professional Engineer

OSHA's general construction definition describes a competent person as someone capable of identifying existing and predictable hazards in the surroundings or working conditions and authorized to take prompt corrective measures. The definition combines knowledge with authority. A technically knowledgeable observer who cannot obtain prompt correction may not satisfy a competent-person

function assigned by a standard; likewise, a manager with authority but without the required hazard knowledge is not automatically competent for a specialized task.

A qualified person is defined differently: a person who, through recognized degree, certificate or professional standing, or extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter, work or project. Particular standards can add more detailed qualification requirements. The terms competent and qualified are therefore not interchangeable. One may emphasize hazard recognition and prompt correction; the other may emphasize technical design, evaluation or problem solving.

Certain OSHA provisions also specifically require design or approval by a registered professional engineer. For example, excavation protective systems used in excavations more than 20 feet deep must be designed by a registered professional engineer under the applicable Subpart P provisions. Scaffolds, by contrast, are generally designed by a qualified person, with specific situations invoking additional engineering requirements. The safest practice is to read the actual provision rather than infer the required credential from the apparent complexity of the task.

ROLE	TASK-SPECIFIC BASIS
Competent person	Hazard-recognition capability and authorization for prompt corrective measures.
Qualified person	Demonstrated subject-matter problem-solving ability through the applicable knowledge, training, experience or credentials.
Registered professional engineer	Engineering design or approval where the applicable standard requires it.
Project engineer / observer	Assigned scope, competence and actual authority; title alone does not establish an OSHA role.

3.2 Excavations and Trenches: Stability Is a System, Not a Visual Impression

Excavation safety depends on more than depth. Soil classification, groundwater, vibration, surcharge loads, nearby foundations, traffic, utilities, spoil placement and weather can alter conditions. Federal OSHA generally requires employees in excavations to be protected from cave-ins by an adequate protective system, with limited exceptions including stable rock or excavations less than five feet where a competent person finds no indication of potential cave-in. Protective systems must resist the loads reasonably expected to be applied to them.

From an engineering perspective, excavation work also creates interface risks. A delivery route may add surcharge near an excavation edge. Dewatering can influence adjacent soils. A utility conflict can force a different alignment. Temporary shoring can interact with a permanent foundation or neighboring structure. A design change can alter the excavation sequence. Those interfaces require coordination between the competent person, contractor, geotechnical or structural expertise where needed, and the project engineer when the permanent design or adjacent assets are affected.

3.3 Scaffolds and Elevated Access: Design, Capacity, Inspection and Change

OSHA requires scaffolds to be designed by a qualified person and constructed and loaded in accordance with that design. Scaffold components are also subject to competent-person inspection and other task-specific requirements. These distinctions matter when engineers encounter unusual loads, attachments, tie-ins, temporary enclosures, hoisting near scaffolds, modifications or interactions with the permanent structure. A field change that increases load or changes support should not be treated as a routine convenience simply because the scaffold remained standing after the change.

Engineers who review attachments to the permanent structure should focus on the engineered interface: connection loads, substrate capacity, conflicts with waterproofing or structural systems, and whether the

proposed attachment is consistent with the design assumptions. The scaffold employer remains responsible for the scaffold system and its OSHA obligations unless responsibility is otherwise established by the facts and applicable law; the engineer should not casually assume operational control by giving informal field directions beyond the engineer's role.

3.4 Cranes, Rigging and Mobile Equipment: Control the Operating Envelope

Cranes and derricks in construction are governed by Subpart CC, which contains detailed requirements for ground conditions, assembly/disassembly, power-line safety, inspections, operators, signal persons, maintenance and other functions. For a professional-engineering CE course, the objective is not to reproduce that standard. The objective is to recognize when a field condition is inside a specialized operating envelope that requires trained, qualified or certified personnel and task-specific controls.

Engineering and project-management interfaces commonly include crane setup near excavations or underground structures, outrigger reactions on slabs or temporary fills, lifts adjacent to energized lines, erection sequences that depend on temporary stability, component weights that differ from drawings, and restricted swing or access zones. If ground capacity, structure capacity or temporary stability is uncertain, obtain the appropriate technical evaluation before proceeding. The presence of an experienced operator does not resolve an engineering uncertainty outside the operator's role, and the presence of an engineer does not replace operator, rigger or signal-person qualifications required by the standard.

3.5 Multi-Employer Worksites: Responsibility Follows Facts and Authority

Construction projects commonly involve owners, general contractors, trade contractors, design professionals, testing agencies, vendors and consultants. OSHA's Multi-Employer Citation Policy recognizes four potential employer roles: creating, exposing, correcting and controlling. More than one employer can be citable for the same hazardous condition, and an employer can occupy more than one role. The policy uses a two-step analysis: identify the employer's role, then determine whether the employer met the obligations associated with that role.

The engineering lesson is to avoid slogans such as “the general contractor is always responsible,” “the subcontractor is responsible only for its own people,” or “the engineer observed it, so the engineer owns it.” Actual authority, exposure, contractual relationships, worksite conduct and response to the condition matter. OSHA's policy also addresses design professionals and does not treat the title architect or engineer alone as sufficient to make a firm a controlling employer. The breadth of actual involvement and authority is relevant.

EMPLOYER ROLE	FACT TO ESTABLISH
Creating	Caused the hazardous condition.
Exposing	Has employees exposed to it.
Correcting	Responsible for correcting it.
Controlling	Has the relevant supervisory authority; evaluate actual control and conduct.

3.6 Temporary Works and Field Changes: Define the Release Condition

High-risk work benefits from a release condition: a short statement of what must be true before work starts or resumes. For an excavation, that may include utility location, competent-person inspection, access, protective-system decision, spoil and equipment control, and water conditions. For a lift, it may include ground conditions, equipment configuration, rigging, communication method, power-line controls and exclusion zones. For temporary structural work, it may include completion of connections, bracing, inspection and confirmation of required design assumptions.

The release condition prevents the schedule from becoming the default decision maker. If the prerequisite cannot be verified, the work remains unreleased until the appropriate party resolves it. This is particularly valuable during design changes or sequence changes because it forces the team to identify which previous assumptions no longer apply.

MODULE 4 | 15 MINUTES

Field response, documentation and verification

A professional response to an unsafe condition is neither passive observation nor uncontrolled overreach. It is a disciplined sequence that protects people, stays within authority, obtains the right technical decision, and verifies closure.

4.1 A Six-Step Response: Pause, Protect, Notify, Escalate, Document, Verify

When a potentially serious hazard is observed, the first objective is to avoid increasing exposure while the condition is evaluated. “Pause” does not necessarily mean shutting down the entire project. It means the affected movement, entry, lift, energization or work step should not continue as though the condition had not changed. The person with immediate authority should stabilize the situation within that authority and keep additional people from entering the hazard zone where reasonably possible.

Next, apply an immediate control that is within the person's authority and competence. A supervisor may stop a crew, establish a barricade, change a sequence or obtain the required competent person. A project engineer may be able to withhold an engineering acceptance, identify a conflict in the design information, request clarification or notify the contractor and owner representative. A worker may move to a safe location and notify supervision. The exact action depends on role; the common objective is to prevent continued exposure while the correct owner is engaged.

Notify the person or employer with responsibility and ability to correct the condition. If the hazard is serious, the correction is delayed, responsibility is disputed or the exposure continues, escalate through the defined chain. Specialized decisions should be made by the person the standard or project requires: competent person, qualified person, registered professional engineer, electrical professional, lift director or other qualified authority as applicable. After the decision is implemented, document and verify. A hazard is not closed merely because an email was sent or a meeting occurred.

1 PAUSE Avoid further exposure.	**2 PROTECT** Act within competence and authority.	**3 NOTIFY** Engage the responsible party.
4 ESCALATE Obtain the required specialized decision.	**5 DOCUMENT** Record facts, actions and ownership.	**6 VERIFY** Confirm the control and release condition.

Use the six steps together: pausing an exposure and obtaining the correct decision do not eliminate the need for documented verification.

4.2 Separate Observation from Technical Direction

Field documentation should distinguish what was observed from conclusions that require specialized authority. “Guardrail missing at opening on Level 3 at 10:20 a.m.; workers redirected and superintendent notified” is an observable record. “Contractor violated OSHA and must install System X” may be inappropriate if the writer lacks responsibility or has not evaluated the applicable standard and

alternatives. Factual documentation protects the project because it preserves the condition, timing, communication and ownership without overstating conclusions.

The same discipline applies to design professionals. If a field condition affects the permanent design, record the technical issue, identify the information needed, evaluate it within the engineer's competence and scope, and issue formal direction through the project's communication system. If the condition is primarily a means-and-methods or employer safety issue, avoid unintentionally taking operational control by prescribing detailed methods unless the engineer is actually responsible and competent to do so. Raise the concern and require the responsible party to provide an acceptable response consistent with the contract and applicable safety requirements.

4.3 Build a Defensible Safety Decision Record

A useful field safety record answers five questions: What condition was observed? Who or what was exposed? What immediate action prevented further exposure? Who owns the final technical or operational decision? What evidence confirms the condition was corrected or controlled? If a design or engineering judgment was involved, the record should also identify the assumptions, documents, calculations, sketches or approvals that support that judgment. The goal is not paperwork for its own sake. The record helps the next person understand why work was stopped, what changed, who decided, and why it was reasonable to resume.

DECISION RECORD	FACT TO PRESERVE
Observation / exposure	Location, time, condition and affected people or work.
Immediate action / boundary	Protection taken within authority and the outstanding specialized decision.
Owner / evidence / release	Responsible party, supporting records and verified condition for resumption.

4.4 Applied Scenario 1 - Delivery Route Beside an Open Excavation

A concrete delivery is approaching an open excavation. The planned haul route places the truck close to the excavation edge, and rain overnight has changed soil and surface conditions. The route was used safely the previous day. The correct response is not “we used it yesterday.” Pause the delivery before the vehicle adds surcharge or enters a questionable route. Engage the excavation competent person, evaluate changed conditions and loads, and determine whether the route must be relocated or otherwise controlled. If the permanent design, adjacent structure or engineered protective system could be affected, obtain the relevant engineering review. Resume only after the release condition is re-established.

4.5 Applied Scenario 2 - Suspended Load Crossing an Active Work Zone

A subcontractor begins a crane lift and the load path passes over an area where another crew has continued working. The immediate problem is exposure beneath or near a suspended load, not the contractual debate about which subcontractor “owns” the area. Stop or redirect the exposed work within available authority, engage the lift supervisor or responsible employer, establish the exclusion zone and communication protocol, and verify the load path before movement resumes. If the lift depends on uncertain ground or structural support, escalate the technical question to the appropriate qualified or engineering authority rather than allowing schedule pressure to resolve it by default.

4.6 Applied Scenario 3 - Temporary Guardrail Removed for Material Movement

A guardrail that was present during the morning inspection is removed so material can be moved through an opening. The material operation finishes, but the guardrail is not restored. Treat the removal as a change in control status. Restrict access or provide an appropriate interim control, notify the employer responsible for the area and the party responsible for restoring protection, and verify the

completed condition. The process should also address recurrence: who is authorized to remove the rail, what alternate protection is required during removal, and who verifies restoration? A repeated missing guardrail is a management-system problem, not only a one-time field defect.

4.7 Applied Scenario 4 - Equipment Near Overhead Power

A boom lift or crane must operate near overhead power, and the crew proposes to “watch the distance carefully.” Visual estimation is not a sufficient engineering or regulatory control. Pause the approach until the applicable clearance, voltage, equipment configuration and control strategy are established by people with the required competence. Coordination may involve the equipment employer, controlling contractor, utility and qualified electrical or lift-planning personnel. The professional lesson is to resolve the energy exposure before movement continues rather than trying to monitor an undefined safe distance in real time.

4.8 Field Safety Action Checklist

AREA	CONTROL QUESTION
Plan	Have work steps, changes, interfaces and credible hazards been reviewed?
Excavation	Are utilities, competent-person inspection, protective-system decisions, loads and water conditions addressed?
Roles	Are required competent, qualified, RPE or other designated roles identified for the task?
Employers	On a multi-employer site, are roles, authority and communication clear?
Access / Falls	Are current routes, openings, edges, platforms and temporary protections controlled?
Change	Has any design, sequence, weather, access, equipment or adjacent-trade change invalidated the prior plan?
Movement	Are vehicle routes, swing radii, suspended-load paths and exclusion zones coordinated?
Documentation	Are observation, immediate control, notification, owner and verification recorded?
Energy	Are electrical, mechanical, hydraulic, pneumatic and stored-energy exposures identified and controlled?
Incident	Does management know who handles emergency response, OSHA reporting decisions, recordkeeping and investigation?

> **Using the checklist.** Use these prompts to record the control owner, evidence and follow-up needed for the work package. They do not replace the applicable OSHA provisions, employer program, task-specific procedures, manufacturer instructions or professional judgment.

Course Summary

Construction safety is strongest when hazards are addressed before exposure and when field changes trigger a deliberate reassessment. Professional engineers contribute by recognizing how design, access, sequence, temporary conditions, equipment interfaces and information quality influence risk; by using Prevention through Design and the hierarchy of controls where engineering decisions can remove or reduce hazards; and by respecting the boundaries between project engineering, employer safety responsibilities and OSHA-defined specialized roles.

The Focus Four provides a practical recognition lens: falls, struck-by, caught-in/between and electrocution. High-risk operations require more than recognition. They require the competent, qualified, registered-professional-engineer or other specialized roles called for by the applicable standard, plus clear ownership and verification of controls. Multi-employer projects add another layer: responsibility depends on actual role, exposure, authority and conduct rather than job title alone.

When an unsafe or changed condition is identified, use the field-response sequence: pause the exposure, protect within authority, notify the responsible party, escalate to the required technical or managerial authority, document the facts and ownership, and verify the correction before closure. This disciplined process protects people while reducing both passive inaction and inappropriate overreach.

Principal references and source links

- OSHA, 29 CFR Part 1926, Safety and Health Regulations for Construction. Consult the operation-specific subpart and applicable state-plan requirements. Open source
- OSHA, 29 CFR 1926.32, Definitions, including competent and qualified persons. Open source
- OSHA, 29 CFR 1904.39, federal severe-event reporting; read timing, delayed-outcome and notification provisions in context. Open source
- OSHA, 29 CFR 1926.652, excavation protective systems; and 1926.451, scaffold requirements. Open source
- OSHA, 29 CFR 1926.451, scaffold design, capacity, inspection and use. Open source
- OSHA, 29 CFR 1926.501, fall-protection duties. Open source
- OSHA CPL 02-00-124, Multi-Employer Citation Policy, December 10, 1999. Open source
- OSHA Construction eTool, Falls. Historical source photograph; its old fatality statistics are not used as current data. Open source
- NIOSH Publication 2024-124, Prevention through Design Toolkit for the Construction Industry, September 2024. Open source

Public sources checked November 15, 2026. Examples distinguish engineering judgment, contractual requirements and mandatory rules. Actual project documents, employer programs, current regulations and qualified professional decisions control implementation.

Instructor

John W. Adcox, Jr., Ed.D., CPC

> **Study guide complete.** Return to the BuilderCE lesson page and select Continue to begin the final examination. A score of at least 70% is required to pass. Retakes are permitted.